



Remove the keys from handle bar by detaching cable tie.  
Note: Reserve one of two keys with the plate imprinted with the key No. at a safety place for just in case of missing or when spare key is needed.



Use the key to unlock the saddle pad from lockable box as shown.



Remove the Red cap for power socket and then connect power plug onto the power socket of battery pack before using the E-Moped.  
Note: The C-LiFePO<sub>4</sub> Battery Pack must be fully charged daily after use and before use of the E-Moped at the first time.  
The charging method can be referred to next page.



Switch off main switch before charging.

Panel of the Off-Board Charger



Charger's ON/OFF Switch

110V/220V Setting Switch

- Note: 1. Must use the PMMC approved charger to charge World Patent PHET C-LiFePO<sub>4</sub> Battery Pack.  
 2. The 110V/220V Setting Switch must be correctly set in accordance with the AC voltage to be applied from the power source outlet, before charging.

**Option 1: Standard On-Board Charging**

- Note: 1. Ensure the battery pack stored inside the lockable box being plugged with battery power cable, as shown.  
 2. The power socket located underneath the lockable box must be plugged with the DC power cable connected with the charger at the DC side and then plug the AC power cord connected with the charger at the AC side to a power source outlet, as shown.



Note 1



AC Side

DC Side

**Option 2: Standard Off-Board Charging**

- Note: Unplug the power cord from the battery pack to be removed from the E-Moped. The power socket of battery box must be plugged with the DC power cable connected with the charger at the DC side and then plug the AC power cord connected with the charger at the AC side to a power source outlet, as shown.



DC Side

AC Side